

# RGB Flipper Button Matrix Connection And Color : Dip Switch Selector



## Color Selection:

- Turn 1 only on = Blue
- Turn 2 only on = Red
- Turn 3 only on = Green

Turn 1 and 2 and 3 on = White

- Turn 1 and 3 on = Turquoise
- Turn 1 and 2 on = Pink
- Turn 2 and 3 on = Aqua

NOTE: Select color then apply Power. Comes with wire harness to attach to the start button.

